



HyDraw CAD 2026 Vault Installation

Warning: Prior to installing the HyDraw CAD Vault Add-On, please ensure that the 'Autodesk Vault Professional 2026 – Client' application is installed on the same system. Without this application, the HyDraw CAD 2026 Vault Add-On will not work.

HyDraw CAD 2026 Vault


Download & save the HyDraw CAD 2026 EN Vault (English region) or HyDraw CAD 2026 IT Vault (Italian region) installation files from following page.

<https://www.vestusa.com/HyDraw-CAD-2026-Vault.htm>


Steps to Get Vault Running with HyDraw CAD:

Step 1. Install Vault Add-On:

- a. Browse to the folder location where the setup file has been downloaded to/saved and run the HyDraw CAD 2026 EN Vault setup.
- b. Click **Unzip**. All HyDraw CAD 2026 installation files will automatically get extracted to default **C:\VEST** folder location.



- c. Setup will automatically start after all files have been successfully extracted.
- d. Click on **Next** to proceed with the installation by following the on-screen prompts.



For support, call +1 (248) 649-9550, or email support@VESTusa.com
In Europe call +39 049 997 00 40, +39 328 6957001, or email carlo.molon@vestusa.com